

29.2500
9.1870
M605
0-16V DC
VOLTS DC
M600
0-100A DC
AMPS DC
BATTERY CONDITION
BILGE PUMP
CIRCUIT BREAKER
OFF
15A
POWER ON
BATTERY TEST
BATT 1
SW405
BATT 2
OPERATION MODE
AUTO
SW400
MANUAL
LIGHT INDICATES BILGE IS BEING PUMPED
R
CAUTION: DISCONNECT SHORE POWER AND BATTERIES BEFORE SERVICING PANEL
MARINCO
12V
Catalina Yachts
12V DC DISTRIBUTION PANEL
LIGHTING
20A PORT CABIN LIGHTS
20A STBD CABIN LIGHTS
10A NIGHT LIGHTS
10A RUNNING LIGHTS
5A STEAMING LIGHTS
5A AUX. ONE
10A DECK LIGHTS
5A ANCHOR LIGHT
20A AUX. LIGHT PANEL
AUX. SYS.
10A CABIN FANS
20A REFRIG.
5A LPG SOLENOID R
AUX. TWO
AUX. THREE
AUX. FOUR
NAV/COMM
10A VHF RADIO
15A RADAR
15A STEREO
15A NAV INSTRUMENTS
10A CHART PLOTTER
30A TELEVISION
25A AUTOPILOT
AUX. FIVE
AUX. SIX
PUMPS
15A WATER PRESS.
10A SHOWER DRAIN PUMPS
25A ELECTRIC HEAD
25A MACERATOR(S)
AUX. SEVEN
AUX. EIGHT
120V AC 30A MAIN PANEL
WARNING!
TO MINIMIZE SHOCK AND FIRE HAZARDS:
1.) TURN OFF THE BOATS SHORE CONNECTION SWITCH BEFORE CONNECTING OR DISCONNECTING CABLE.
2.) CONNECT SHORE POWER CABLE AT BOAT FIRST.
3.) IF POLARITY WARNING INDICATOR IS ACTIVATED IMMEDIATELY DISCONNECT CABLE.
4.) DISCONNECT SHORE POWER CABLE AT SHORE OUTLET.
5.) CLOSE SHORE POWER INLET COVER TIGHTLY. DO NOT ALTER SHORE POWER CABLE CONNECTORS.
15A PORT OUTLETS
30A SHORE POWER MAIN BREAKER 30 AMP DUAL
15A STBD OUTLETS
15A WATER HEATER
POWER ON G
15A BATTERY CHARGER
REVERSED POLARITY R
AC AUX.
PUSH TO TEST LAMP
PB 4650