

Catalina Direct Offshore Sails Full Batten Installation Instructions



**Specialists in Catalina
Parts & Accessories for 40 years**

For technical support call 916-843-1971

**10210 Systems Parkway, Suite 390
Sacramento, CA 95827**

© 2014 The Foredeck



Step 1

Insert the batten into the inner opening of the pocket.



Step 2

Place the end of the injector into the slot on the leech tab.



Step 3

Push the leech tab into the outer opening of the pocket.



Step 4

Continue pushing until there is a firm tension on the batten.



Step 5

Press against the velcro to secure it.



Step 6

Tuck the retriever loop just into the edge of the velcro.



Batten Removal

- 1) Removal retriever loop from edge of Velcro
- 2) Insert injector to release Velcro
- 3) Remove injector
- 4) Pull firmly on retriever loop to remove flap